

<i>Dolphin Remote Codes</i>	
Device	Code
Sony VCR	0032
Sony CD	1397
T.View	0813
Farenheit DVD16T	0887
Farenheit DVD11T/12T	1054
Farenheit DVD11N	1066
Farenheit DVD5	0890
Blaupunk DVD	0717
13" TV	0463
15" LCD TV	0801
17" LCD TV	0180
Directed Video Tuner	1131
Amtran Cable Tuner	1359
19" TV	1868
15" Digital TV	1244
KEC DVD	1238
KEC DVD '07	1146
Clarion	1669
Kenwood	0337
MBQuartz DVD/CD	1318

- 1) Select Device - LED Blink 1
- 2) Press+Hold Setup - LED Blink 1 then 2
- 3) Enter Numeric Code - LED Blink 2